

Thank you for choosing our Finnish Wall mask. Please read these instructions concerning use, maintenance and the warranty carefully.

This Wall goalie mask is designed and manufactured to protect the goalie's head in normal practice and game situations.

This mask meets the minimum requirements of performance specifications provided it has not been reconditioned or altered in any way.

The mask does not entirely eliminate the risk of injury and it does not protect from possible neck and spine injuries.

In order to achieve maximum protection and comfort, the mask must be the right size and adjusted correctly. If necessary, use fitting pieces that can be purchased separately.

Before use

- Adjust the 5-point straps tightly enough so that the mask sits firmly on the head and the forehead rests against the sweat band.
- Adjust the chin cup to the right tightness by either removing the securing screws and placing the screws in the right places on the strap or by adjusting the Velcro tape on the strap, depending on the model. A chin cup that is too loose causes a serious risk of injury.
- Check the tightness of all screws and tighten them, if necessary.

Use and maintenance of the mask

- The protector should be replaced if it has been exposed to violent impact or other stress that may have reduced its protective function.
- Always visually inspect the condition of the entire mask after use.
- Check the tightness of all screws regularly and tighten them, if necessary. Do not use screw locking varnishes or glues, as they may weaken the structure of the mask.
- Always check that the chin cup is firmly fastened before use.
- Always check the condition of the cage following an impact. If the wires of the cage have become twisted or the welded seams appear damaged, the cage must be replaced with a new one. You can unscrew the securing screws on the sides of the cage to check that the cage does not cause strain on the shell of the mask.
- If you notice any cracks, flaws or other damage on the shell of the mask, contact the manufacturer to make sure that the mask is safe.
- You can use water and mild detergents to clean the mask. Do not leave a wet mask in an equipment or carrying bag, instead hang it out to dry in a well-ventilated space.

Warranty

Wall Masks provides a one (1) year limited warranty on the plastic or fiber-structured shell of its masks. The warranty period begins on the date of purchase. When complaining about a flaw, the buyer must submit a warranty certificate, a receipt or other reliable proof of where and when the mask was purchased.

The warranty does not cover cosmetic damage, such as scratches caused by impacts of the puck etc., minor flaws in the coat of paint or varnish, nor the fasteners, such as the clips, press studs, straps and screws.

The warranty does not cover damage to the mask due to the strain of a twisted cage. A twisted cage must be replaced with a new, original Wall cage. Twisted wires on the cage and possible minor flaws in the paint do not fall under the warranty.

Using other manufacturers' spare parts in the mask, neglecting the instructions concerning mask maintenance and use or applying the wrong kind of paint or coating may cause the warranty to become void.

The buyer must notify the warrantor or the vendor of a flaw within a reasonable time from noticing the flaw or when he or she should have noticed it.

Wall Masks should be primarily contacted directly in issues related to the warranty. Contacts by e-mail to wall@wallmask.fi. If the product has a flaw covered by the warranty, Wall Masks reserves the right to either repair or replace only the damaged part of the product. Wall Masks shall not be liable for any indirect damage caused by the breaking of a mask.